CONCEALED SPRINKLER WRENCH-ABLE CAPS

Simple, effective sprinkler protection that lowers risk and liability.

Provided with Model RFC, G5, and LT56C sprinklers.

Using the Model W3 wrench, sprinklers are installed without removing the protective cap.

Indicator on cap for alignment with nominal finished ceiling location.

Caps project beyond sprinkler cup and are angled out to help avoid damaging ceiling finish.

Cap color indicates sprinkler temperature rating.

Cap can be removed with a standard 1/2" NPT or BSPT threaded adapter on pipe.

Adhesive backed silicone disk available to create a cover plate installation tool.





